

SAVE THESE INSTRUCTIONS! - READ AND KEEP FOR FUTURE REFERENCE.

Pressure Regulator Instructions

The Pressure Regulator Knob controls the cooking function. Align the **ARROW** on the regulator knob with the **INDICATOR MARKS** on the regulator mount.

Use the **STEAM** setting for keep warm, slow cook, steam and to release pressure at the end of the pressure cooking cycle. Use the **PRESSURE** setting for cooking under high or low pressure and rice setting.

To set regulator knob for **STEAM** setting - Place cooker on the counter with control panel facing you. Turn the regulator knob until the **ARROW** aligns with the first **MARK** on the regulator mount.

To set regulator knob for **PRESSURE** setting - Place cooker on the counter with control panel facing you. Turn the regulator knob until the **ARROW** aligns with the second **MARK** on the regulator mount.

